





4B Components Limited

Automatic Level Control Wiring High and Low Level Overview




High Level
Contact Closed

Low Level
Contact Closed




EMPTY

NOTE: CONTROL RELAY "R" STARTS AND STOPS THE FILLING OF THE CONTAINER




High Level
Contact Closed

Low Level
Contact Open




LOW LEVEL
FILLED



High Level
Contact Open

Low Level
Contact Open



FULL